



Walkway Water Drainage System

List of Tools Needed, Shopping List, and Installation Instructions

 Medium Capacity
  **11-13 Hours**
Total Man Hours
  **\$380-\$45**
Material Costs
  10 Tools Needed

TOOLS NEEDED



Saw



Level



Measuring Tape



Pick



PVC Glue



Shovel



Plastic or Tarp

Trenching Machine
(Optional)Clear Waterproof
Silicone

Concrete

SHOPPING LIST

Quantity needed of each part will vary based on several factors specific to your project including system length, rainfall intensity, and number of problem areas. Pipe and fittings are offered in two sizes: 3" and 4". Size availability will vary based on region and store.

Ensure that component sizes are consistent throughout your drainage system.

Add on new line:

Refer to drainage calculators on NDSPRO.com for pipe & system sizing.

NDS Part Number	Description
321 or 421	3" or 4" Pop-up Emitter with Elbow
FWAS24	Flo-Well
FWSD69	Flo-Well Surface Drain
400	4' Spee-D Channel Drain
241	2' Spee-D Channel grate
247	Spee-D Channel End Cap
248	Spee-D Channel Coupler
234	Spee-D Channel Bottom Outlet
3P02 or 4P02	3" or 4" Sewer and Drain Elbow
Generic	3" or 4" SDR35 Drain Pipe
Generic	1/2" Rebar

INSTALLATION INSTRUCTIONS



Note Before You Dig

Prior to installation, have your local utility companies locate and mark the location of existing utilities. Layout your drainage system and mark the location of trenches and individual parts to be installed with marking paint before digging. Carefully remove grass or plants that are located where the trench will be dug so they can be replanted after installation. Trenches should be dug such that they slope a minimum of 1% away from your house. Place all excavated dirt on a tarp so that it can be used later to backfill.

To speed up installation, a trenching machine can be used to dig all trenches, especially in areas with particularly hard soil. NDS drainage products have been designed to be installed in any soil type. Due to the variety of pipe types and sizes, double check that all pipe connection points are the correct size. Please follow all installation directions included with the individual parts of your drainage system. To create watertight connections between products, apply a bead of waterproof silicone to both parts and connect.

This system requires that the elevation of the Pop-Up Emitter be lower than the elevation of the area drain or the system will not drain.

Step 1:

Lay out system, dig trenches and holes

Dig trench for EZ-Drain, channel drain and Flo-Well. Flo-Well(s) should be installed under the areas where the runoff is collecting. Dry fit (no glue) the entire drainage system from the channel drain to the Pop-Up Emitter. The Flo-Well should be installed at least 10' away from any existing structure. Measure and cut all pipe to necessary lengths. After completing each step, glue parts together if a water tight connection is required.



TIP: If installing the drain in an existing concrete area, a wet concrete saw will be required to cut the concrete prior to installation.

Step 2:

Install Spee-D Channel Drain

Compact the soil where the Spee-D Channel Drain will be installed to prevent settling. The Spee-D Channel Drain should be installed a minimum of 1/8" below the finished grade of the surrounding surface. Connect the required number of Spee-D Channel Sections together using Spee-D Channel Drain Couplers. Place the Spee-D Channel Drain grates on the channel and screw in place. Place Spee-D Channel Drain End Caps at the end of the runs as needed.



Step 3:

Connect elbow to drain on channel

Determine the way which the Spee-D Channel Drain will be drained (either via an End Outlet or Bottom Drain) and connect the appropriate drain pipe. Glue and connect elbows as needed. Continue drain pipe in the direction of where the Flo-Well will be installed.



Step 4:

Install Flo-Well and EZ-Drain

Run drain pipe from the Spee-D Channel Drain to the Flo-Well. Knock out the appropriate holes in the side panels of the Flo-Well where the drain pipe and EZ-Drain will be installed. Assemble the Flo-Well using the interlocking side panels. Slide the Drain Pipe and EZ-Drain through the holes in the Flo-Well side panels.



TIP: Lay the Flo-Well panels on bricks or other hard surfaces and use a hammer to knock out the holes in the side panels.

Step 5:

Connect Flo-Well Surface Inlet

Knock out the center hole of the Flo-Well lid. Place the lid on the Flo-Well side panels then place the Flo-Well Surface Inlet onto the Flo-Well lid.



Step 6:

Install Pop-Up Emitter

Using a Corrugated Pipe Adapter, connect the EZ-Drain to an elbow with a weep hole. The elbow should be installed with the weep hole on the horizontal side of the elbow. Slide the Pop-up Emitter onto the elbow. An additional length of pipe can be used between the elbow and Pop-Up Emitter to bring the Pop-up emitter to the surface. The Pop-Up Emitter fits on the “bell” or “hub” end of the pipe or a pipe coupler.



TIP: To avoid damaging your Pop-Up Emitter with your lawnmower, raise the cutting level of the blades or avoid passing the mower over the Pop-Up Emitter.

Step 7:

Backfill and Replant

Cover the Spee-D Channel Drain grate with tape and cement, or grout, the channel into place. Remove tape after concrete or grout is dry. Backfill trenches and replace any grass or plants that were removed.

TIP: DO NOT BACKFILL WITH SOIL WITH HIGH CLAY CONTENT. Water must be able to easily pass through the backfilled soil.

