




NDS, INC.
 851 NORTH HARVARD AVE.
 LINDSAY, CA 93247
 TOLL FREE: 1-800-726-1994
 PHONE: (559) 562-9888
 FAX: (559) 562-4488
 www.ndspro.com




LAYOUT

LEGEND:

- ① DRIP MANIFOLD FROM FILTERED AND REGULATED ZONE VALVE KIT (SIZED TO MEET LATERAL FLOW DEMAND)
- ② PVC DRIP MANIFOLD PIPE
- ③ PVC SCHEDULE 40 "T" OR "L"
- ④ BLANK TUBING LENGTH AS REQUIRED, AGRIFIM A660/BR
- ⑤ BARB X BARB INSERT AGRIFIM "T" = T17
- ⑥ PROJECTED CANOPY LINE OF TREE OR SHRUB
- ⑦ ON-SURFACE DRIP LINE, AGRIFIM DURA-FLO CV
- ⑧ ROOTBALL (TYPICAL)
- ⑨ BARB X BARB INSERT AGRIFIM "X" = CR17
- ⑩ FLUSH POINT, AGRIFIM CEP18 (TYPICAL)
- ⑪ SPACING PER SPECIFICATION
- ⑫ TIE DOWN STAKE, AGRIFIM S8

NOTES:

1. INSTALL MULTIPLE RINGS AS REQUIRED TO PROVIDE COVERAGE FROM ROOTBALL TO PROJECTED TREE CANOPY. REFER TO AGRIFIM DESIGN GUIDELINES FOR RECOMMENDED SPACING BETWEEN RINGS.
2. PLACE TIE-DOWN STAKES EVERY 3'-0" O.C. IN SAND, 4'-0" O.C. IN LOAM AND 5'-0" IN CLAY SOILS.
3. AT FITTINGS WHERE THERE IS A CHANGE OF DIRECTION SUCH AS TEES OR ELBOWS, USE TIE-DOWN STAKES ON EACH LEG OF THE CHANGE OF DIRECTION.
4. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
5. DO NOT SCALE DRAWING.
6. THIS DRAWING IS INTENDED FOR USE BY ARCHITECTS, ENGINEERS, CONTRACTORS, CONSULTANTS AND DESIGN PROFESSIONALS FOR PLANNING PURPOSES ONLY.
7. ALL INFORMATION CONTAINED HEREIN WAS CURRENT AT THE TIME OF DEVELOPMENT BUT MUST BE REVIEWED AND APPROVED BY THE PRODUCT MANUFACTURER TO BE CONSIDERED ACCURATE.



AGRIFIM

DURA-FLO CV - ON-SURFACE DRIPLINE MULTI TREE SHRUB DETAIL